









<p>Step 1</p> 	<p>Step 2</p> 
<p>Insert base legs into uprights to make L shape for wall shelving or T shape for gondola shelving. To insert the base legs, locate the two upper lugs into the upright and rotate downwards to locate the lower lug, use a rubber mallet to tap the base leg into position</p>	<p>Hold two uprights the appropriate distance apart and insert a back panel into both uprights. The back panel should locate into the inside slot of each upright. The shelving should be levelled at this point using the adjustable feet.</p>
<p>Step 3</p> 	<p>Step 4</p> 
<p>Attach the kick panel to the base feet using the slots in a similar fashion to the back panel.</p>	<p>Place base shelf onto base legs and then complete adding the back panels. If small back panels are used, put these on first.</p>
<p>Step 5</p> 	<p>Step 6</p> 
<p>Once all the back panels are fitted, you are ready to add the shelves</p>	<p>The brackets should be positioned in the H slot of the upright and should be located in the inside slot (the back panel and bracket for the next shelving bay will use the other slot). The 3 hook brackets can be horizontal or tilted upwards or downwards as required.</p>
<p>Step 7</p> 	<p>Step 8</p> 
<p>Repeat step 6 with the required number of brackets and then lower the correct size shelf onto the brackets.</p>	<p>Finally add any shelf ticket strips, risers and dividers.</p>